



Installation Instructions for 4 Piece Remodeler Shower & Tubs with Pin System

Models: SR4363777 (Shown)/SRLB4/RB483677/SRDS4483677/TR4543077/TR4603177/TTR4603177/SR4603177/STRRB4/LB603182/SRRB4/LB603182/SR4603182/TR4603477/SHR4603478/SHRRB4/LB603478/THR4603480/SRRB4/LB603677/SRDS4603677/SHR4603778

- 1.) Carefully disassemble unit by removing all of the "shipping" hardware and discard. Note that pins will stay in place.
- 2.) Remove the side walls by pulling forward until the pins are cleared.
- 3.) Remove the back wall by lifting up vertically until the back pin is cleared.
- 4.) Place tub/shower base in alcove. Make sure and level base. Pre-drill holes and secure flange to studs with SS hardware.
- 5.) Set the back wall panel. Put a 1/4" bead of silicone caulk where the back panel sits on the base. Fill all shipping bolt holes with caulk as well. Place back panel over locating pin. Drill holes through flanges and secure flange to studs with SS screws.
- 6.) Set the left side panel. Put a 1/4" bead of silicone caulk vertically on the back panel and to the top of the base where the side panel will sit. Place side panel down on base and slide tight over the 3 locating pins on the back panel. Drill holes through flanges and secure the left side panel to studs with SS screws. Repeat the process for the right side panel.

